



INLET
ELBOW

TANK
BAFFLE

TANK

Instanta
DB1000TF (CTS10TF)

D.111

Exploded Drawing Key for CTS10TF

Number	Description	Part Number
1	Main P.C.B.	XEF402BSP
2	Sensor-beam-break P.C.B.	XEF406SP
3	Triac (3KW)	XE851SP
4	Beam-break cables (emitter/receiver set)	XEF410SP
5	Inlet Solenoid Valve	SOL12SP
6	Silicone rubber water-feed pipe (grey) per metre	ACC309SSP
7	Tank Gasket	XENPB510SP
8	Element (3kW) c/w washers & hex nuts	XEN175SP
9	Separate element washers	XEN100WSP
10	Thermistor (Temp Sensor) Probe-type	XE853PRBSP
11	Water level Probe assembly (3 per machine)	PRB12A
12	Boil-dry element thermal cut-out	XETR5SP
13	Hot Water Dispense valve	SOL24SP
14	Silicone rubber boot (for hot water valve)	SOL19WSP
15	Over-boil thermal safety cut-out	XETR7SP
16	Boiler foot c/w rubber Insert & screw	D208SP
17	Sensor PCB c/w spacer	XEF407SP
18	P.C.B. LCD screen	XEF404SP
19	Dark grey plastic facia	DBPLA2SP
~	Complete Drip-Tray for DB500/1000	DBDT2SP